

About us

Welcome to **Crushwell Solutions**, your trusted partner in quality spare parts and services. We specialise in supplying appropriate and durable spare and wear parts for a wide range of crushers used in mining, quarrying and construction applications. We are committed to quality, reliability, on-time delivery, competitive pricing and customer satisfaction.

Our vision and mission


Our mission at Crushwell Solutions is to deliver spare parts and services that ensure optimal performance, minimize downtime, and maximize productivity. We are dedicated to providing customized solution and required technical support.

Our vision is to be your one-stop solution provider for providing premium spare parts and expert services. We aim to be your first choice whenever your crushing equipment faces downtime, because the problem is not yours, it's ours!

Our Values

- [] Reliable and dependable partner
- [] Customer centric approach
- [] Integrity and transparency
- [] Trust & Long term relation with stakeholder

QUALITY SPARES, TRUSTED SOLUTIONS.




Get in touch with us today and let us help you keep your crushing equipment's performing at their best.

Sri Ram Colony, Rajgangpur-770017, Odisha, T: +91 8249488138 / 8929123623
crushwellsolutions@gmail.com | enquiry@crushwellsolutions.com | sales@crushwellsolutions.com

**Crushwell**
SOLUTIONS

High-performance Cone Crusher Wear and Spare Parts

High-performance cone crusher wear and spare parts are essential for achieving smooth production flow. We supply a diverse range of spare parts for leading crusher brands, available in standard or customized configurations to fit your application.




Spare & Wear Parts

Arm Guard



Bearing



Bearings



Bottom Liners



Bushing



Case



Concave



Counter Shaft



Cover



Damper Pad




Dust Seal



Gear & Pinion Set



Hat



Head



Hub New



Pulley




Setting Piston



Slide Ring



Locking Ring




Main Shaft




Mantle



Slip Ring



Top Bearing



Top Protection Plate



Middle Thrust Bearing



O-Ring



Oil Seal



Torch Ring



Protection Bushing



Protection Plate



Protection Plate




Non Ferrus Parts


Bearing




Eccentric Bushing



Frame Bushing



Thrust Bearing



Thrust Bearing

