

About us

Welcome to **Crushwell Solutions**, your trusted partner in quality spare parts and services. We specialise in supplying appropriate and durable spare and wear parts for a wide range of crushers used in mining, quarrying and construction applications. We are committed to quality, reliability, on-time delivery, competitive pricing and customer satisfaction.

Our vision and mission


Our mission at Crushwell Solutions is to deliver spare parts and services that ensure optimal performance, minimize downtime, and maximize productivity. We are dedicated to providing customized solution and required technical support.

Our vision is to be your one-stop solution provider for providing premium spare parts and expert services. We aim to be your first choice whenever your crushing equipment faces downtime, because the problem is not yours, it's ours!

Our Values

- [] Reliable and dependable partner
- [] Customer centric approach
- [] Integrity and transparency
- [] Trust & Long term relation with stakeholder

QUALITY SPARES, TRUSTED SOLUTIONS.





Get in touch with us today and let us help you keep your crushing equipment's performing at their best.

Sri Ram Colony, Rajgangpur-770017, Odisha, T: +91 8249488138 / 8929123623
crushwellsolutions@gmail.com | enquiry@crushwellsolutions.com | sales@crushwellsolutions.com

The logo for Crushwell Solutions, featuring a gear icon above the word 'Crushwell' in a bold, sans-serif font, with 'SOLUTIONS' in a smaller, all-caps font below it.


High-Performance Vertical Shaft Impactor Wear & Spare Parts

Ensure uninterrupted production with our premium wear and spare parts for Vertical Shaft Impactors. We offer a comprehensive range of components compatible with leading crusher brands—available in both standard and custom configurations to suit your specific operational needs.



Spare & Wear Parts

Anvil




Back Up Tip Casting



Bearings



Rotor



Shaft



Tip



Cavity Ring




Damper Pad



Distributer Plate




Top Plate



Top Taper Ring Casting



Top Wear Plate



Distributer Plate



Feed Eye Ring



Feed Eye Ring



Trail Plate



Upper Wear Plate



Housing



Lower Wear Plate



Rotor Tips

